Procedimento para habilitar a gerencia remota em ONU Fiber Home

Acessar o equipamento e ir até os seguintes MENU


Logout
Status
Network
Security
Application
Management
Firewall
Remote Control
Remote Control
DDOS
HTTPS
Security » Remote Control » Remote Control
Apply
Cancel

On this page, you can enable/disable visit web through wan, you can not visit web through wan if you disable remote control, and you can visit web through wan if you enable remote control.

Remote Control ● Enable ○ Disable

Em seguida alterar a porta padrão


Status
Network
Security
Application
Management
DDNS
Port Forwarding
NAT
UPNP
DMZ
Web Port
Web Port
Diagnosis
Application » Web Port » Web Port
Apply
Cancel

Ont this page, you could configure web communication port(HTTP), and restart to be effective.

WEB valid communication port 2015

WEB communication port you modified 0 *(Please input 1024-65535 or 80)