




Configuração IPv6 Mikrotik


Observação

Caso o menu IPv6 não esteja disponível, o mesmo deve ser habilitado acessando System / packages e em seguida reiniciar o equipamento



Acesse o MENU IPv6 DHCP Client e execute os passos como indicam as setas


No campo interface deverá ser colocado o pppoe criado.





Em seguida *IPv6 / Addresses* e adicione como indicam as setas

Observe que a interface é a LAN do cliente



Acesse o site test-ipv6.com

O resultado deve ser como o abaixo.

Test your IPv6 connectivity.

SummaryTests RunShare Results / ContactOther IPv6 SitesFor the Help Desk

Your IPv4 address on the public Internet appears to be 192.0.2.1

Your IPv6 address on the public Internet appears to be 2001:db8:4901:2791:5ad:a529:d9d6:ce

Your Internet Service Provider (ISP) appears to be EXAMPLE-ISP - US

Since you have IPv6, we are including a tab that shows how well you can reach other IPv6 sites. [\[more info\]](#)

Good news! Your current configuration will continue to work as web sites enable IPv6.

Your DNS server (possibly run by your ISP) appears to have IPv6 Internet access.

Your readiness score

10/10 for your IPv6 stability and readiness, when publishers are forced to go IPv6 only

Click to see [test data](#)

(Updated server side IPv6 readiness stats)