

Configuração WIFI china Telecom (Nokia)

Acesse o equipamento (observe se a interface esta igual a a seguir)

Acesse o Menu *STATUS* e em seguida *DEVICE INFO*; role a barra lateral até encontrar as configurações de wireless. Encontrando, clique em *Wireless configuration guide* (Observe que tem os campos de 2.4 e 5.8 ghz)

The screenshot displays the Nokia GPON Gateway web interface. The top navigation bar includes 'Status', 'Network', 'Security', 'Application Management', 'Diagnostic', and 'Help'. The 'Status' page is active, showing a sidebar with 'Device Info' and 'Config Guide'. The main content area is divided into sections: 'Device Information', 'PON Information', 'Wireless Information', 'Wireless Information(5G)', and 'User Ethernet Information'. Red arrows highlight the 'Status' menu, the 'Device Info' link in the sidebar, the 'Wireless Information' section, and the 'wireless configuration guide' link within the 'Wireless Information' section.

Status GPON Gateway Type: HGU

Device Info Config Guide

Device Information

Device Type:	GPON
Manufacturer:	NBEL
Model Name:	G-140W-MF
Serial Number:	AC9CE4-00000ACA46E6234D0
Hardware Version:	3FE47510AAAA
Software Version:	3FE46343AFIA95

PON Information

Link Protocol:	GPON
Connection Status:	Connected
Connection Time:	2hours24minutes6seconds
Transmit Optical Power:	1.805559 dBm
Receive Optical Power:	-13.487220 dBm

Wireless Information

Wireless Network Name:	SPEED-LAB
Wireless Network Secret Key:	cliente@speed
Open/Close:	Open
Security Mode:	WPA2 Pre-Share Key
wireless configuration guide	

Wireless Information(5G)

Wireless Network Name:	SPEED-LAB-5G
Wireless Network Secret Key:	cliente@speed
Open/Close:	Open
Security Mode:	WPA2 Pre-Share Key
wireless configuration guide	

User Ethernet Information

Ethernet Port1:	Not connected devices
Ethernet Port2:	Not connected devices
Ethernet Port3:	Not connected devices

Altere como a seguir (O campo SSID sempre ficara com a informação “SPEED-” antes do nome da rede). Após concluir clique em aplicar

Device Info

Config Guide

Wireless Security Settings

Configuration of basic Wi-Fi features including enabling/disabling the Wi-Fi, setting Wi-Fi SSID, data encryption, network authentication and key length.

Enable Wi-Fi

SSID Select

Enable SSID

SSID

Authentication Protocol:

WAN Connection:

Wi-Fi Password

Save/Apply

Key Display

Após aplicar, retorne no menu status, siga os mesmos passos e agora configure a rede 5G

Open/Close:	Open
Security Mode:	WPA2 Pre-Share Key
wireless configuration guide	

Wireless Information(5G)

Wireless Network Name:	SPEED-LAB-5G
Wireless Network Secret Key:	cliente@speed
Open/Close:	Open
Security Mode:	WPA2 Pre-Share Key
wireless configuration guide	

Device Info

Config Guide

Wireless Security Settings

Configuration of basic Wi-Fi features including enabling/disabling the Wi-Fi, setting Wi-Fi SSID, data encryption, network authentication and key length.

Enable Wi-Fi

SSID Select

Enable SSID

SSID

Authentication Protocol:

WAN Connection:

Wi-Fi Password

Save/Apply

Key Display